



26534
26533

26522



Enarmsdrift drivenhet Etac Cross 6, Cross, Cross XL, Cross 5, Cross 5 XL, Prio


Single-hand drive Etac Cross 6, Cross, Cross XL, Cross 5, Cross 5 XL, Prio


Einhandantrieb Etac Cross 6, Cross, Cross XL, Cross 5, Cross 5 XL, Prio


74542.12 2022-10-19

1


Cross 6, Cross 5, Cross 5 XL


x2 


x6 





Cross, Cross XL


x2 

x2 


x2 


x2 


x2 




Prio


x2 

x2 

x2 




27317, 27318, 27319,
27320, 27321





--	--	--	--	--	--	--





Cross 6, Cross 5, Cross 5 XL



Cross, Cross XL



Prio



I position D3 med sits- och ryggvinkelbegränsningar
 In position D3 with seat / back tilt limitations
 In Position D3 mit Sitz- / und Rückenwinkeleinschränkungen