


## **Cross vest**

When considering using vests and belts for a child, it is important to choose the correct size in order to ensure the correct positioning and fit. When measuring the child, the measurements should be taken with a flexible tape measure in order to follow the curves of the body.





Provides a firm and flexible hold against the front and sides of the trunk. It aims to prevent the child from falling forward or sideways.

For the cross vest, the measurement should be taken from the widest part of the shoulder (S) to the opposite side of the pelvis (P).

	XS	S	M	L	XL
Shoulder (S) to Pelvis (P)	73/4"-121/2"	101/4" – 131/2"	13½"-17¾"	173/4"-203/4"	203/4"-241/2"

Vests and belts R82 | by Etac